




EOS 40D

REF. NO. C12-6171

PARTS CATALOG

CANON EOS 40D




PARTS LIST

Pg. 1

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
*	CB3-3744-000 000	C	1	COVER, INTERFACE
*	CB3-3745-000 000	B	1	CAP, INTERFACE
*	CB3-3748-000 000	B	1	COVER, BACK HOLDING
*	CB3-3749-000 000	B	1	TAPE, DOUBLE SIDE
*	CB3-3769-000 000	C	1	CASE, BATTERY
*	CB3-3972-000 000	C	1	CAP, EXTENSION TERMINAL
*	CB3-3975-000 000	B	1	COVER, GRIP HOLDING
*	CB3-3976-000 000	B	1	COVER, FRONT
*	CB3-3977-000 000	B	1	TAPE, DOUBLE SIDE
*	CB3-3978-000 000	B	1	TAPE, DOUBLE SIDE
*	CB3-3980-000 000	B	1	TAPE, DOUBLE SIDE
*	CB3-4164-000 000	B	1	TAPE, DOUBLE SIDE
*	CB3-4175-000 000	C	1	RING, O
*	CG2-2024-000 000	B	1	COVER ASS'Y, BATTERY
	XA1-7170-507 000	F	3	SCREW, CROSS-RECESS, PH

CANON EOS 40D




P A R T S L I S T

Pg. 2

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB2-0726-000 000	C	2	SCREW, M17X5.5
	CB2-0727-000 000	C	1	SCREW, M1.7X4.5
*	CB3-3974-000 000	C	1	SHEET, EXTENSION TERMINAL
*	CB3-4148-000 000	C	2	SCREW
*	CB3-4149-000 000	C	4	SCREW
*	CG2-2023-000 000	B	1	COVER ASS'Y, FRONT
	XA1-7170-357 000	F	2	SCREW, CROSS-RECESS, PH
	XA1-7170-507 000	F	3	SCREW, CROSS-RECESS, PH
	XA4-9170-457 000	F	1	SCREW, CROSS-RECESS, PH

CANON EOS 40D




PARTS LIST

Pg. 3

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB2-0726-000 000	C	1	SCREW, M17X5.5
*	CB3-3795-000 000	C	1	DIAL, DIOPTER CORRECTION
*	CB3-3796-000 000	C	1	SCREW
*	CB3-3846-000 000	B	1	WINDOW, DISPLAY
	CB4-0038-000 000	B	3	SCREW, CROSS-RECESS, PH
*	CG2-2016-000 000	C	1	COVER ASS'Y, BOTTOM
*	CG2-2018-000 000	B	1	COVER ASS'Y, TOP
*	CY3-1577-000 000	B	1	LABEL, BODY NUMBER
	XA4-9170-457 000	F	1	SCREW, CROSS-RECESS, PH
	XA4-9170-607 000	F	1	SCREW, CROSS-RECESS, PH

CANON EOS 40D




PARTS LIST

Pg. 4

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB3-2808-000 000	C	2	SCREW
*	CB3-3822-000 000	C	3	SCREW
*	CB3-3863-000 000	C	1	CUSHION, TRIPOD
*	CB3-3942-000 000	C	1	SHEET, BOTTOM
*	CB3-3943-000 000	C	1	PLATE, GROUND (EXT. TERMINAL)
*	CB3-3944-000 000	C	1	CUSHION, MAIN-CAPACITOR
*	CG2-2014-000 000	C	1	FPC ASS'Y, AF
*	CG2-2015-000 000	C	1	PLATE ASS'Y, BASE
*	CG2-2046-000 000	C	1	PCB ASS'Y, BOTTOM
*	CH1-8517-000 000	C	1	FPC, BOTTOM-MAIN
	XA1-7170-307 000	F	2	SCREW, MACH. PANHEAD, M1.7X3
	XA4-9170-457 000	F	1	SCREW, CROSS-RECESS, PH
	XA4-9200-457 000	F	2	SCREW, CROSS-RECESS, PH
	XD1-1102-120 000	F	2	WASHER, COP

CANON EOS 40D



CB2-0682-000(XXX) detail

	A ±	SIZE
	0.03mm	(003)
	0.05mm	(005)
	0.08mm	(008)
	0.10mm	(010)
	0.12mm	(012)
	0.15mm	(015)
	0.18mm	(018)
	0.20mm	(020)
	0.25mm	(025)
	0.30mm	(030)
	0.35mm	(035)


PARTS LIST

Pg. 5

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB2-0682-000 (XXX)	C	3	WASHER, FLANGE BACK
*	CB3-3931-000 000	C	1	COVER, MAIN PCB SHIELD
*	CB3-3941-000 000	C	1	PLATE, GROUND (USB)
*	CG2-2012-000 000	B	1	PCB ASS'Y, MAIN
*	CH1-8495-000 000	C	1	FPC, MAIN-DCDC
*	CY3-1576-000 000	B	1	CMOS SENSOR ASS'Y
	XA1-7170-207 000	F	2	SCREW
	XA1-7170-307 000	F	5	SCREW, MACH. PANHEAD, M1.7X3
	XA4-9170-457 000	F	3	SCREW

CANON EOS 40D




P A R T S L I S T

Pg. 6

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
*	CB3-3809-000 000	C	2	SCREW
*	CB3-4132-000 000	C	1	PLATE, GROUND (MAIN-SHUTTER)
*	CG2-2008-000 000	C	1	PLATE ASS'Y, MAIN BASE
*	CG2-2011-000 000	B	1	PCB ASS'Y, DC/DC
*	CH2-8439-000 000	C	1	WIRE,LEAD
*	CH2-8440-000 000	C	1	WIRE,LEAD
	XA1-7170-307 000	F	1	SCREW, MACH. PANHEAD, M1.7X3
	XA4-9170-359 000	F	2	SCREW, CROSS-RECESS, PH
	XA4-9170-457 000	F	6	SCREW, CROSS-RECESS, PH

CANON EOS 40D




P A R T S L I S T

Pg. 7

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-9007-000 000	C	1	RING, PC RETAINER
	CB3-3374-000 000	C	1	JACK, REMOTE-CONTROL
*	CB3-3768-000 000	C	1	COVER, CF SLOT
*	CB3-3785-000 000	C	1	CUSHION, CF SLOT1
*	CB3-3786-000 000	C	1	CUSHION, CF SLOT2
*	CB3-3787-000 000	C	1	HOLDER, STRAP RIGHT
*	CG2-2010-000 000	B	1	TERMINAL ASS'Y, PC
*	CG2-2050-000 000	C	1	FPC ASS'Y, REMOTE CONTROL
*	CG2-2057-000 000	C	1	FPC ASS'Y, CF DOOR
*	CG2-2058-000 000	C	1	FPC ASS'Y, BATTERY COVER
	XA1-7170-207 000	F	1	SCREW, CROSS-RECESS, PH
	XA4-9170-307 000	F	2	SCREW, CROSS-RECESS, PH
	XA4-9170-457 000	F	5	SCREW, CROSS-RECESS, PH

CANON EOS 40D




PARTS LIST

Pg. 8

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-4085-000 000	C	4	SCREW, M2X6.5
	CB2-0727-000 000	C	2	SCREW, M1.7X4.5
	CB3-1700-000 000	C	1	MOUNT
	CB3-1742-000 000	C	1	SHEET, SHUTTER LIGHT SHIELD
*	CB3-3802-000 000	C	1	COVER, SCREEN RETAINER
*	CB3-3805-000 000	C	1	PLATE, SCREEN RETAINER
*	CB3-3819-000 (XXX)	C	1	WASHER, FINDER BACK ADJUST
*	CB3-3821-000 000	C	2	SCREW
*	CB3-3901-000 000	B	1	TAPE, DOUBLE SIDE
	CF1-1948-000 000	C	1	LENS LOCK PIN ASS'Y
*	CG2-1992-000 000	B	1	MIRROR BOX ASS'Y
*	CG2-2003-000 000	C	1	EYEPiece ASS'Y
*	CG2-2017-000 000	B	1	FPC ASS'Y, AE
*	CG2-2031-000 000	B	1	SHUTTER ASS'Y
*	CG2-2070-000 000	C	1	CONTACT ASS'Y, LENS
*	CH9-1112-000 000	C	1	FPC ASS'Y, SI
	CS2-5020-000 000	C	1	SPRING, COIL
	CS2-7205-000 000	C	1	SPRING, MOUNT
	XA4-9170-457 000	F	2	SCREW, CROSS-RECESS, PH
	XA4-9170-507 000	F	6	SCREW, CROSS-RECESS, PH
*	XD1-1101-831 000	F	2	WASHER
*	YN2-9695-000 000	C	1	PLATE, SI INDICATE
*	YN2-9715-000 000	B	1	PLATE, FOCUSING SCREEN

CANON EOS 40D




PARTS LIST

Pg. 9

REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
*	CB3-3754-000 000	C	1	BUTTON, MENU/PRINT
*	CB3-3755-000 000	C	1	BUTTON, PRINT
*	CB3-3762-000 000	C	1	HOLDER, TFT
*	CB3-3763-000 000	B	1	WINDOW, TFT DISPLAY
*	CB3-3764-000 000	B	1	TAPE, DOUBLE SIDE
*	CB3-4079-000 000	C	1	SHEET, BACK COVER
*	CB3-4141-000 000	C	1	SHEET, TFT
*	CB3-4248-000 000	C	1	GASKET
*	CG2-1990-000 000	B	1	COVER ASS'Y, BACK
*	CG2-2059-000 000	C	1	FPC ASS'Y, TFT
*	CH2-8435-000 000	C	1	WIRE, LEAD
	CH9-1106-000 000	B	1	LCD ASS'Y, TFT
	XA4-9170-307 000	F	5	SCREW, CROSS-RECESS, PH

CANON EOS 40D




PARTS LIST

Pg. 10



REF. NO. C12-6171

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB3-1816-000 000	F	3	SCREW
	CB3-3507-000 000	C	1	SHOE, ACCESSORY
	CB3-3508-000 000	C	1	SPRING, ACC.SHOE PLATE
*	CB3-3835-000 000	C	1	HOLDER, STRAP LEFT
*	CB3-3836-000 000	C	1	COVER, FLASH
*	CB3-4183-000 000	C	1	BASE, ACC.SHOE CONTACT
*	CB3-4635-000 000	C	4	SCREW, M1.7X5.2
*	CG2-2019-000 000	C	1	DIAL ASS'Y
*	CG2-2020-000 000	C	1	LCD ASS'Y, OUTSIDE
	WC2-5568-000 000	B	1	SWITCH, RELEASE (MECH)
	XA4-9170-457 000	F	7	SCREW, CROSS-RECESS, PH
	XA4-9170-607 000	F	2	SCREW, CROSS-RECESS, PH

Accessories

Wide Strap EW-100DGR


N.S (Product Available)

**Battery Pack 511A
(BP-514/BP-511/BP-512)****Battery Charger CG-580**


N.S (Product Available)

**Interface Cable
IFC-200 U**


N.S (Product Available)

Battery Charger CB-5L

N.S (Product Available)

Video Cable VC-100

N.S (Product Available)

AC POWER CABLE

D82-0643(EUROPE)
D82-0645-001(AUSTRALIA)
C50-8221(CHINA)

AC POWER CABLE

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	D82-0643-000 000	C	1	CABLE, AC, EUROPE
	D82-0645-001 000	A	1	CABLE, AC, AUSTRALIA
	C50-8221-000 000	C	1	CABLE, AC, CHINA

BATTERY PACKBP-511A

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	DA3-1929-000 000	C	1	COVER, TERMINAL BP-514/BP-511A

INDEX OF PARTS LIST

NEW	PARTS NO.	PAGE	NEW	PARTS NO.	PAGE
	C50-8221-000 000	11	*	CB3-3821-000 000	8
	CA1-9007-000 000	7	*	CB3-3822-000 000	4
	CB1-4085-000 000	8	*	CB3-3835-000 000	10
	CB2-0682-000 (XXX)	5	*	CB3-3836-000 000	10
	CB2-0726-000 000	2	*	CB3-3846-000 000	3
	CB2-0726-000 000	3	*	CB3-3863-000 000	4
	CB2-0727-000 000	2	*	CB3-3901-000 000	8
	CB2-0727-000 000	8	*	CB3-3931-000 000	5
	CB3-1700-000 000	8	*	CB3-3941-000 000	5
	CB3-1742-000 000	8	*	CB3-3942-000 000	4
	CB3-1816-000 000	10	*	CB3-3943-000 000	4
	CB3-2808-000 000	4	*	CB3-3944-000 000	4
	CB3-3374-000 000	7	*	CB3-3972-000 000	1
	CB3-3507-000 000	10	*	CB3-3974-000 000	2
	CB3-3508-000 000	10	*	CB3-3975-000 000	1
*	CB3-3744-000 000	1	*	CB3-3976-000 000	1
*	CB3-3745-000 000	1	*	CB3-3977-000 000	1
*	CB3-3748-000 000	1	*	CB3-3978-000 000	1
*	CB3-3749-000 000	1	*	CB3-3980-000 000	1
*	CB3-3754-000 000	9	*	CB3-4079-000 000	9
*	CB3-3755-000 000	9	*	CB3-4132-000 000	6
*	CB3-3762-000 000	9	*	CB3-4141-000 000	9
*	CB3-3763-000 000	9	*	CB3-4148-000 000	2
*	CB3-3764-000 000	9	*	CB3-4149-000 000	2
*	CB3-3768-000 000	7	*	CB3-4164-000 000	1
*	CB3-3769-000 000	1	*	CB3-4175-000 000	1
*	CB3-3785-000 000	7	*	CB3-4183-000 000	10
*	CB3-3786-000 000	7	*	CB3-4248-000 000	9
*	CB3-3787-000 000	7	*	CB3-4635-000 000	10
*	CB3-3795-000 000	3		CB4-0038-000 000	3
*	CB3-3796-000 000	3		CF1-1948-000 000	8
*	CB3-3802-000 000	8	*	CG2-1990-000 000	9
*	CB3-3805-000 000	8	*	CG2-1992-000 000	8
*	CB3-3809-000 000	6	*	CG2-2003-000 000	8
*	CB3-3819-000 (XXX)	8	*	CG2-2008-000 000	6

INDEX OF PARTS LIST

Pg. 13

REF. NO. C12-6171

NEW	PARTS NO.	PAGE	NEW	PARTS NO.	PAGE
*	CG2-2010-000 000	7		XA1-7170-307 000	4, 5, 6
*	CG2-2011-000 000	6		XA1-7170-357 000	2
*	CG2-2012-000 000	5		XA1-7170-507 000	1, 2
*	CG2-2014-000 000	4		XA4-9170-307 000	7, 9
*	CG2-2015-000 000	4		XA4-9170-359 000	6
*	CG2-2016-000 000	3		XA4-9170-457 000	2, 3, 4, 5, 6, 7, 8, 10
*	CG2-2017-000 000	8		XA4-9170-507 000	8
*	CG2-2018-000 000	3		XA4-9170-607 000	3, 10
*	CG2-2019-000 000	10		XA4-9200-457 000	4
*	CG2-2020-000 000	10	*	XD1-1101-831 000	8
*	CG2-2023-000 000	2		XD1-1102-120 000	4
*	CG2-2024-000 000	1	*	YN2-9695-000 000	8
*	CG2-2031-000 000	8	*	YN2-9715-000 000	8
*	CG2-2046-000 000	4			
*	CG2-2050-000 000	7			
*	CG2-2057-000 000	7			
*	CG2-2058-000 000	7			
*	CG2-2059-000 000	9			
*	CG2-2070-000 000	8			
*	CH1-8495-000 000	5			
*	CH1-8517-000 000	4			
*	CH2-8435-000 000	9			
*	CH2-8439-000 000	6			
*	CH2-8440-000 000	6			
	CH9-1106-000 000	9			
*	CH9-1112-000 000	8			
	CS2-5020-000 000	8			
	CS2-7205-000 000	8			
*	CY3-1576-000 000	5			
*	CY3-1577-000 000	3			
	D82-0643-000 000	11			
	D82-0645-001 000	11			
	DA3-1929-000 000	11			
	WC2-5568-000 000	10			
	XA1-7170-207 000	5, 7			