

作成承認印

配布許可印



D40

VBA15001 Black

VBA15101 Silver

P A R T S L I S T

修 理 部 品 表

Nikon | **NIKON CORPORATION**
Tokyo, Japan

Copyright© 2006 by NIKON CORPORATION.

All Rights Reserved.


無断転載を禁ず！！




Fig. 1

△ 1C999-476-1(1) NEW
1C999-476(1) OLD

1



2



3

☆印は VBA15101 シルバー部品
☆VBA15101 (Silver Parts)


Fig. 2

△1C999-476(1) OLD

1

2

3



☆印は VBA15101 シルバー部品
 ☆VBA15101 (Silver Parts)

Fig. 3

A

B

INC

VBA15001-R.3701.A




Fig. 3-1

A

B


INC

VBA15001-R.3701.A

1

2

3



A

B


INC

VBA15001-R.3701.A

1

2

3



☆印は VBA15101 シルバー部品
☆VBA15101 (Silver Parts)

A

B

INC

VBA15001-R.3701.A

1K103-869(5)

1F998-248(1)

1K010-781x2(10)

1K241-651(5)

1K010-770(10)

1K001-340(10)

1K241-652(5)

1K241-494(5)

1K010-781x2(10)

1F998-293(1)

1K233-277(5)

1F998-272(5)

1K104-660x2 (10)

1K010-782x2(10)

1K104-519(5)

1K103-274(5)

2

1G480-067(5)

1F998-270(1)

1G780-033(5)

1K602-987(5)

1K010-773(10)

△1G680-058(5)

3

Fig. 5

☆印は VBA15101 シルバー部品
 ☆VBA15101 (Silver Parts)

Fig. 6

A

B


INC

VBA15001-R.3701.A

1

2

3



☆印は VBA15101 シルバー部品
 ☆VBA15101 (Silver Parts)

Fig. 7

A

B

INC

VBA15001-R.3701.A

1

2

3




Fig. 8

☆印は VBA15101 シルバー部品
☆VBA15101 (Silver Parts)

A

B

INC

VBA15001-R.3701.A

Fig. 8

1

2

3




Fig. 9

☆印は VBA151001 シルバー部品
☆VBA15101 (Silver Parts)

A

B

INC

VBA15001-R.3701.A

1

1K001-329x5(10)

1F998-287(1)

1K104-533(5)

1S477-001(5)

1K104-535(5)

2

1K001-327x3(10)

1K103-331-1x0~3(5)

6K050-084~086x0~n(10)

1F998-303(1)

3

1K104-592(5)




Fig. 9

Fig. 10

☆印は VBA15101 シルバー部品
 ☆VBA15101 (Silver Parts)

A

B

INC

VBA15001-R.3701.A

1

1K087-760(5)

1K104-529(5)

1K683-478(1)
☆1K683-485(1)

1K201-446(5)
 ☆1K201-453(5)
 1K201-447(5)
 ☆1K201-454(5)
 1K201-448(5)
 ☆1K201-455(5)
 1K201-449(5)
 ☆1K201-456(5)

1S758-139(5)

1K087-741(5)

1K201-450(5)
☆1K201-457(5)

1K682-924(5)

1S758-140(5)

A


1K104-668(10)

1K104-531x2(5)

1K104-530x2(5)

1S570-003(1)

2

1K201-445(5)
☆1K201-452(5)

1S020-453(5)

1K201-444(5)
☆1K201-451(5)

1K104-536x2(5)

1K110-855(5)

1K602-994(5)

1S422-090(5)

1K010-790x3
(10)

1K104-537(5)

1K103-858(5)

1K104-538(5)

1F998-313(1)
☆1F998-282(1)

3

1K683-479(5)
☆1K467-290(5)

A

1K602-696-1(5)

1K010-800x2 (10)
☆1K010-792x2 (10)1K683-480(5)
☆1K683-486(5)

1K104-532x2(5)

☆印は VBA15101 シルバー部品
 ☆VBA15101 (Silver Parts)

Fig. 11

A

B

INC

VBA15001-R.3701.A

1

1K010-798x2(10)
 ☆1K010-768x2(10)

1K001-336x4(10)
 1K001-351x4(10)
 ☆1K001-324x4(10)
 ☆1K001-350x4(10)

Fig. 11

1K467-287(5)
 ☆1K467-288(5)

2

Fig. 10

3

1F998-259(1)

1K104-494(5)

1K050-938x0~1
 (10)

1K001-337x4(10)
 ☆1K001-334x4(10)

1K683-452(1)
 ☆1K683-483(1)

1K010-799x5(10)
 ☆1K010-769x5(10)

1K087-445(5)

1K087-756J(5)
 1K087-756U(5)

☆印は VBA15101 シルバー部品
 ☆VBA15101 (Silver Parts)



1K467-286(5)
 ☆1K467-289(5)

Fig. 12

Parts List

D40(Black)

VBA15001-R.3701.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1B061-012		シャッター SHUTTER	1	4		1	
1B061-012		SHUTTER					
* 1C998-416		着脱釦部組 LENS RELEASE BUTTON UNIT	1	3, △3-1		5	RP07022
1C998-416		LENS RELEASE BUTTON UNIT					
1C999-476		前板部組 FRONT BODY UNIT	1	2,3		1	△ OLD RP07022
1C999-476		FRONT BODY UNIT					
△ 1C999-476-1		前板部組 FRONT BODY UNIT	1	2,3-1		1	NEW RP07022
1C999-476-1		FRONT BODY UNIT					
1C999-478		上カバー部組(BLACK) TOP COVER UNIT(BLACK)	1	7		1	
1C999-478		TOP COVER UNIT(BLACK)					
1F998-248		ペンタ部組 PENTA UNIT	1	6		1	
1F998-248		PENTA UNIT					
1F998-256		底基板部組 BOTTOM BASE PLATE UNIT	1	5		1	
1F998-256		BOTTOM BASE PLATE UNIT					
1F998-258		吊り環部組 EYELET RING UNIT	2	1		5	
1F998-258		EYELET RING UNIT					
1F998-259		電池蓋部組 BATTERY CHAMBER UNIT	1	12		1	
1F998-259		BATTERY CHAMBER UNIT					
1F998-266		SQ基板部組 SQ BASE UNIT	1	3, △3-1		1	RP07022
1F998-266		SQ BASE UNIT					
1F998-270		接眼鏡筒部組 EYE PIECE BARREL UNIT	1	6		1	
1F998-270		EYE PIECE BARREL UNIT					
1F998-271		接眼枠 EYEPiece FRAME	1	9		1	
1F998-271		EYEPiece FRAME					
1F998-272		SI押え部組 SI RETAINER UNIT	1	6		5	
1F998-272		SI RETAINER UNIT					
1F998-276		シューモールド部組 SHOE MOLD UNIT	1	7		5	
1F998-276		SHOE MOLD UNIT					
1F998-277		AF補助光部組 AF ASSIST LAMP UNIT	1	7		5	
1F998-277		AF ASSIST LAMP UNIT					
1F998-283		SB SW部組 SB SW UNIT	1	4		1	
1F998-283		SB SW UNIT					
1F998-285		ブザー部組 BUZZER UNIT	1	1		5	
1F998-285		BUZZER UNIT					
1F998-286		2次電池 SECOND BATTERY	1	1		1	
1F998-286		SECOND BATTERY					

Parts List

D40(Black)

VBA15001-R.3701.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1F998-287		TOGO基板部組	1	10		1	
1F998-287		TOGO PCB UNIT					
1F998-291		SW FPC	1	9		5	
1F998-291		SW FPC					
1F998-292		上カバーFPC部組	1	7		1	
1F998-292		TOP COVER FPC UNIT					
1F998-293		AE FPC部組	1	6		1	
1F998-293		AE FPC UNIT					
1F998-294		F内LCD部組	1	4		1	
1F998-294		IN FINDER LCD UNIT					
1F998-298		レンズ接点部組	1	3, 3-1		5	RP07022
1F998-298		LENS CONTACT UNIT					
1F998-299		AFセンサー部組	1	4		1	
1F998-299		AF-SENSOR UNIT					
1F998-300		ミラー部組	1	2		1	
1F998-300		MIRROR UNIT					
1F998-301		SB下ケース部組	1	8		1	
1F998-301		SB LOWER CASE UNIT					
1F998-302-1		SB解除基板部組	1	8		1	RP07021
1F998-302-1		SB RELEASE BASE UNIT					
1F998-303		CCD部組	1	10		1	
1F998-303		CCD UNIT					
1F998-307		C/D部組	1	7		5	
1F998-307		C/D UNIT					
△ 1F998-309		前カバー部組	1	9		1	RP07031
△ 1F998-309		FRONT COVER UNIT					
1F998-309N		前カバー部組	1	9		1	RP07031
1F998-309N		FRONT COVER UNIT					
1F998-310		リリース釦部組	1	8		1	
1F998-310		RELEASE BUTTON UNIT					
1F998-311		モードダイヤル部組	1	7		1	
1F998-311		MODE DIAL UNIT					
1F998-313		SD蓋部組	1	11		1	
1F998-313		SD COVER UNIT					
* 1G480-067		F内表示用プリズム	1	6		5	
* 1G480-067		FINDER DISPLAY PRISM					

Parts List

D40(Black)							VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1G680-058 1G680-058		AEセンサーフィルター AE SENSOR FILTER	1	3-1 	1C999-476-1	5	RP07022
1G780-033 1G780-033		SI表示板 SI DISPLAY PLATE	1	6		5	
* 1G950-116 1G950-116		スクリーン FOCUS SCREEN	1	4		5	
1K001-327 1K001-327		ネジ SCREW	3	10		10	
1K001-329 1K001-329		ネジ SCREW	5	10		10	
1K001-331 1K001-331		ネジ SCREW	1	5		10	
1K001-332 1K001-332		ネジ SCREW	4	1		10	
1K001-336 1K001-336		ネジ (L=5.5) SCREW (L=5.5)	4	12		10	
1K001-337 1K001-337		ネジ SCREW	4	12		10	
1K001-338 1K001-338		ネジ SCREW	2	9		10	
1K001-339 1K001-339		ネジ SCREW	2	5		10	
1K001-340 1K001-340		AEセンサー 調整ネジ AE SENSOR ADJUSTMENT SCREW	1	6		10	
1K001-351 1K001-351		ネジ (L=5.0) SCREW (L=5.0)	4	12		10	
* 1K010-569-1 1K010-569-1		ネジ SCREW	3	4		10	
* 1K010-749 1K010-749		ネジ SCREW	3	11		10	
* 1K010-753 1K010-753		ネジ SCREW	5	3, 3-1	1C999-476 1C999-476-1	10	RP07022
* 1K010-754 1K010-754		ネジ SCREW	1	8		10	

Parts List

		D40(Black)					VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 1K010-755 1K010-755		ネジ SCREW	4	7	1C999-478 1C999-475	10	
* 1K010-758 1K010-758		ネジ SCREW	1	3, △3-1	1C999-476 △1C999-476-1	10	RP07022
1K010-770 1K010-770		ネジ SCREW	1	6		10	
1K010-771 1K010-771		ネジ SCREW	2	8		10	
1K010-773 1K010-773		ネジ SCREW	9	1,3,4, 6,8		10	
1K010-774 1K010-774		ネジ SCREW	1	7	1C999-478 1C999-475	10	
1K010-775 1K010-775		ネジ SCREW	4	1		10	
1K010-776 1K010-776		ネジ SCREW	5	5		10	
1K010-777 1K010-777		ネジ SCREW	2	3, △3-1	1C999-476 △1C999-476-1	10	RP07022
1K010-778 1K010-778		ネジ SCREW	4	5		10	
1K010-779 1K010-779		ネジ SCREW	1	9		10	
1K010-780 1K010-780		ネジ SCREW	2	8		10	
1K010-781 1K010-781		ネジ SCREW	12	4,6, 7,9		10	
1K010-782 1K010-782		ネジ SCREW	7	3,6 △3-1	1C999-476 △1C999-476-1	10	RP07022
1K010-783 1K010-783		ネジ SCREW	1	2	1C999-476 △1C999-476-1	10	RP07022
1K010-784 1K010-784		ネジ SCREW	1	7	1C999-478 1C999-475	10	
1K010-786 1K010-786		ネジ SCREW	1	3, △3-1	1C999-476 △1C999-476-1	10	RP07022

Parts List

D40(Black)							VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K010-790 1K010-790		ネジ SCREW	7	1,4, 9,11		10	
1K010-792 1K010-792		ネジ SCREW	4	4,9		10	
1K010-793 1K010-793		ネジ SCREW	1	8		10	
1K010-797 1K010-797		ネジ SCREW	4	9		10	
1K010-798 1K010-798		ネジ SCREW	2	12		10	
1K010-799 1K010-799		ネジ SCREW	5	12		10	
1K010-800 1K010-800		ネジ SCREW	2	11		10	
1K050-938 1K050-938		ワッシャー(T=0.05) WASHER(T=0.05)	0-1	12		10	
* 1K087-445 1K087-445		原産国テープ(MT) COUNTRY ORIGIN TAPE	1	12		5	
* 1K087-741 1K087-741		SDカード挿入指示シール SD CARD LABEL	1	11		5	
1K087-756J 1K087-756J		定格銘板 RATING PLATE	1	12		5	
1K087-756U 1K087-756U		定格銘板(US) RATING PLATE(US)	1	12		5	
1K087-757 1K087-757		銘板 NAME PLATE (BLACK)	1	9	1F998-309	5	
1K087-760 1K087-760		TFT窓 TFT WINDOW	1	11		5	
* 1K103-274 1K103-274		視野枠2 FINDER FIELD FRAME 2	1	6		5	
* 1K103-331-1 1K103-331-1		ルミラーシート LUMIRROR SHEET	0-3	10		5	
* 1K103-491 1K103-491		スペーサー(T=0.11) SPACER(T=0.11)	0-2	4		5	



Parts List

Parts List		D40(Black)					VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 1K103-492 1K103-492		スペーサー(T=0.16) SPACER(T=0.16)	0-2	4		5	
* 1K103-493 1K103-493		スペーサー(T=0.2) SPACER(T=0.2)	0-2	4,9		5	
* 1K103-494 1K103-494		スペーサー(T=0.25) SPACER(T=0.25)	0-2	4		5	
* 1K103-858 1K103-858		両面テープ BOTH SIDED ADHESIVE TAPE	1	11		5	
* 1K103-869 1K103-869		テープ TAPE	1	6		5	
* 1K104-101-1 1K104-101		ショート防止テープ TAPE	3	1,7, 8		5	
1K104-494 1K104-494		電池装填シール BATTERY LABEL	1	12	1F998-259	5	
1K104-496 1K104-496		平板 FLAT PLATE	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K104-498 1K104-498		両面テープ BOTH SIDED ADHESIVE TAPE	3	1,5		5	
1K104-504 1K104-504		シート SHEET	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K104-505 1K104-505		両面テープ BOTH SIDED ADHESIVE TAPE	1	3-1	1C999-476-1	10	RP07022
1K104-508 1K104-508		メインミラー受けモルト MAIN MIRROR SPONGE	1	3, △3-1	1F998-298	5	RP07022
1K104-509 1K104-509		遮光モルト LIGHT SHIELD SPONGE	1	3, △3-1	1F998-298	5	RP07022
1K104-510 1K104-510		植毛紙A FLOCKED SHEET A	1	2	1C999-476 △1C999-476-1	5	RP07022
1K104-511 1K104-511		植毛紙B FLOCKED SHEET B	1	2	1C999-476 △1C999-476-1	5	RP07022
1K104-512 1K104-512		植毛紙C FLOCKED SHEET C	1	2	1C999-476 △1C999-476-1	5	RP07022
1K104-516 1K104-516		ゴミ防止モルト DUST PREVENT SPONGE	1	3-1 △ 4	△1C999-476-1	5	RP07022
1K104-517 1K104-517		モルト SPONGE	2	4		5	

Parts List

Parts List		D40(Black)					VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K104-518		スーパーインポーズ [※] 拡散板	1	3-1	△1C999-476-1	5	RP07022
1K104-518		SUPER IMPOSE DIFFUSER		△ 4			
1K104-519		視野枠1	1	6		5	
1K104-519		FINDER FIELD FRAME 1					
1K104-520		F内表示部防塵部材	1	4		5	
1K104-520		DUST PREVENT SEAT					
1K104-524		両面テープ [°]	1	5		5	
1K104-524		BOTH SIDED ADHESIVE TAPE					
1K104-525		防塵テープ [°]	3	1		5	
1K104-525		DUSTPROOF TAPE					
1K104-529		TFT窓両面テープ [°]	1	11		5	
1K104-529		BOTH SIDED ADHESIVE TAPE					
1K104-530		防塵モルト	2	11		5	
1K104-530		DUSTPROOF SPONGE					
1K104-531		防塵モルト	2	11		5	
1K104-531		DUSTPROOF SPONGE					
1K104-532		両面テープ [°]	2	11		5	
1K104-532		BOTH SIDED ADHESIVE TAPE					
1K104-533		両面テープ [°]	1	10	1F998-287	5	
1K104-533		BOTH SIDED ADHESIVE TAPE					
1K104-535		カバー板	1	10	1F998-287	5	
1K104-535		COVER PLATE					
1K104-536		両面テープ [°]	2	11		5	
1K104-536		BOTH SIDED ADHESIVE TAPE					
1K104-537		両面テープ [°]	1	11		5	
1K104-537		BOTH SIDED ADHESIVE TAPE					
1K104-538		ショート防止テープ [°]	3	4,9, 11		5	
1K104-538		TAPE					
1K104-548		モルト	1	4		5	
1K104-548		SPONGE					
1K104-549		モルト	1	3-1	△1C999-476-1	5	RP07022
1K104-549		SPONGE		△ 4			
1K104-550		スペーサー(T=1.0)	0~n	9		10	
1K104-550		SPACER(T=1.0)					



Parts List

D40(Black)							VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K104-551		スペーサー(T=1.5)	0-n	9		10	
1K104-551		SPACER(T=1.5)					
1K104-552		スペーサー(T=2.0)	0-n	9		10	
1K104-552		SPACER(T=2.0)					
1K104-553		スペーサー(T=2.5)	0-n	9		10	
1K104-553		SPACER(T=2.5)					
1K104-592		モルト	1	10		5	
1K104-592		SPONGE					
1K104-649		ルミラーシート	0-2	9		10	
1K104-649		LUMIRROR SHEET					
1K104-650		SBアッパ衝撃吸収ゴムA	2	7	1C999-478	5	
1K104-650		SB CUSHION RUBBER A			1C999-475		
1K104-660		スポンジ	2	6		10	
1K104-660		SPONGE					
1K104-668		モルト	1	11		10	
1K104-668		SPONGE					
1K110-855		マルチセクターゴム	1	11		5	
1K110-855		MULTI SELECTOR RUBBER					
* 1K119-646		モルト	1	2	1C999-476	5	RP07022
1K119-646		SPONGE			△ 1C999-476-1		
1K201-434		Fmin連動ブロック	1	9		5	
1K201-434		Fmin COUPLING BLOCK					
1K201-441		＋／絞り釦	1	8		5	
1K201-441		＋／APERTURE BUTTON					
1K201-442		INFO.釦	1	8		5	
1K201-442		INFO. BUTTON					
1K201-443		AF/AEロック釦	1	7	1C999-478	5	
1K201-443		AF/AE LOCK BUTTON					
1K201-444		マルチセクター	1	11		5	
1K201-444		MULTI SELECTOR					
1K201-445		OK釦	1	11		5	
1K201-445		OK BUTTON					
1K201-446		背面4連釦A	1	11		5	
1K201-446		REAR PUSH BUTTON A					

Parts List

D40(Black)

VBA15001-R.3701.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K201-447		背面4連釦B	1	11		5	
1K201-447		REAR PUSH BUTTON B					
1K201-448		背面4連釦C	1	11		5	
1K201-448		REAR PUSH BUTTON C					
1K201-449		背面4連釦D	1	11		5	
1K201-449		REAR PUSH BUTTON D					
1K201-450		背面削除釦	1	11		5	
1K201-450		REAR DELETE BUTTON					
* 1K220-377		AFセンサー調整ハネ	3	4		10	
1K220-377		AF-SENSOR ADJUSTMENT SPRING					
* 1K220-628		レンズ着脱釦ハネ	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K220-628		LENS RELEASE BUTTON SPRING					
1K225-376		ミラーアップハネ	1	2	1C999-476 △1C999-476-1	5	RP07022
1K225-376		MIRROR UP SPRING					
1K225-377		絞り駆動ハネ	1	2	1C999-476 △1C999-476-1	5	RP07022
1K225-377		APERTURE ACTUATING SPRING					
1K225-378		絞り戻しハネ	1	2	1C999-476 △1C999-476-1	5	RP07022
1K225-378		APERTURE RESET SPRING					
* 1K233-182		スクリーン押えハネ	1	4		5	
1K233-182		FOCUS SCREEN RETAINER SPRING					
1K233-272		SBアップハネ	1	8		5	
1K233-272		FLASH UP SPRING					
1K233-274		ミラーダウンハネ	1	2	1C999-476 △1C999-476-1	5	RP07022
1K233-274		MIRROR DOWN SPRING					
1K233-277		AEセンサー 調整ハネ	1	6		5	
1K233-277		AE SENSOR ADJUSTMENT SPRING					
* 1K241-426		モードダイヤルクリック板	1	7	1C999-478 1C999-475	5	
1K241-426		MODE DIAL CLICK PLATE					
* 1K241-443-2		バヨネットハネ	3	3, △3-1	1C999-476 △1C999-476-1	10	RP07022
1K241-443		BAYONET SPRING					
* 1K241-450		電源ダイヤルブラシ	1	8		5	
1K241-450		POWER DIAL SW BRUSH					
* 1K241-494		ペンタ押さえハネ1	1	6		5	
1K241-494		PENTA SPRING 1					

Parts List

D40(Black)							VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 1K241-504 1K241-504		モードダイヤル接点ブラシ MODE DIAL BRUSH	1	7	1C999-478 1C999-475	5	
1K241-642 1K241-642		Fmin SW A Fmin SW A	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K241-643 1K241-643		Fmin SW B Fmin SW B	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K241-644 1K241-644		マウントGND板A GND PLATE A	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K241-645 1K241-645		マウントGND板B GND PLATE B	1	3, △3-1	1C999-476 △1C999-476-1	5	RP07022
1K241-649 1K241-649		接点パネ CONTACT SPRING	3	1		5	
1K241-650 1K241-650		電池脱落防止パネ BATTERY LOCK SPRING	1	1		5	
1K241-651 1K241-651		ペンタ押さえパネ2 PENTA SPRING 2	1	6		5	
1K241-652 1K241-652		AE センサー板パネ AE SENSOR FLAT SPRING	1	6		5	
1K241-662 1K241-662		電源ダイヤルクリックパネ POWER DIAL CLICK SPRING	1	8		5	
1K241-663 1K241-663		シューパネ SHOE SPRING	1	7	1C999-478 1C999-475	5	
1K310-258 1K310-258		ミラーアップレバー MIRROR UP LEVER	1	2	1C999-476 △1C999-476-1	5	RP07022
1K310-259 1K310-259		絞り駆動レバー APERTURE DRIVING LEVER	1	2	1C999-476 △1C999-476-1	5	RP07022
1K310-260 1K310-260		絞りレバー APERTURE LEVER	1	2	1C999-476 △1C999-476-1	5	RP07022
* 1K360-430 1K360-430		主ミラー軸 MAIN MIRROR SHAFT	2	2	1C999-476 △1C999-476-1	5	RP07022
1K360-433 1K360-433		SBケース回転軸 SB CASE ROTATE SHAFT	1	8		5	
1K360-435 1K360-435		サブミラー転向ピン SUB MIRROR PIN	1	2	1C999-476 △1C999-476-1	5	RP07022

Parts List

Parts List		D40(Black)					VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K404-176		バヨネット	1	3,	1C999-476	5	RP07022
1K404-176		BAYONET		△3-1 △	1C999-476-1		
1K467-286		電源コード蓋	1	12		5	
1K467-286		POWER CABLE COVER					
1K467-287		I/F蓋	1	12		5	
1K467-287		I/F COVER					
* 1K601-859		シュー裏打ち板	1	7	1C999-478	5	
1K601-859		SHOE PLATE			1C999-475		
1K601-957		シュー座	1	7	1C999-478	5	
1K601-957		SHOE BASE UNIT			1C999-475		
* 1K602-153		合致調整ワッシャー (T=0.1)	0-1	4		5	
1K602-153		WASHER(T=0.1)					
* 1K602-154		合致調整ワッシャー (T=0.2)	0-1	4		5	
1K602-154		WASHER(T=0.2)					
* 1K602-696-1		SD蓋ゴム	1	11	1F998-313	5	
1K602-696-1		SD COVER RUBBER			1F998-282		
1K602-982		DC/DCラグ板	1	1		5	
1K602-982		DC/DC LUG PLATE					
1K602-987		AE FPC押さえ板	1	6		5	
1K602-987		AE FPC RETAINER PLATE					
1K602-994		TFT押さえ板	1	11		5	
1K602-994		TFT RETAINER PLATE					
* 1K631-316		Sチャージレバーカラー	1	2	1C999-476	5	RP07022
1K631-316		S CHARGE LEVER COLLAR			△ 1C999-476-1		
* 1K631-317-1		絞りレバーカラー	1	2	1C999-476	5	RP07022
1K631-317-1		APERTURE LEVER COLLAR			△ 1C999-476-1		
* 1K682-766-1		レンズ着脱釦カバー	1	9		5	
1K682-766		LENS RELEASE BUTTON COVER					
* 1K682-924		アクセスランプ窓	1	11		5	
1K682-924		ACCESS LAMP WINDOW					
* 1K683-281		AF補助光プロテクター	1	7	1C999-478	5	
1K683-281		AF ASSIST LAMP PROTECTOR			1C999-475		
1K683-452		底カバー	1	12		1	
1K683-452		BOTTOM COVER					



Parts List

D40(Black)							VBA15001-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K683-454N 1K683-454N		グリップカバー GLIP COVER	1	9	1F998-309 1F998-251	1	RP07031
1K683-455N 1K683-455N		グリップ赤モールド GRIP RED MOLD	1	9	1F998-309 1F998-251	5	RP07031
1K683-456 1K683-456		レンズ着脱基板 LENS RELEASE BASE PLATE	1	3, 3-1	1C999-476 1C999-476-1	5	RP07022
1K683-459 1K683-459		SB上ケース SB UPPER COVER	1	8		1	
1K683-462 1K683-462		電池ボックス BATTERY CHAMBER	1	1		5	
1K683-463 1K683-463		リモコン受けブロック REMOTE BLOCK	1	9		5	
1K683-473 1K683-473		上カバー飾り板 COVER PLATE	1	7	1C999-478 1C999-475	1	
1K683-475 1K683-475		メインコンデンサホルダー MAIN CONDENSER HOLDER	1	5		5	
1K683-478 1K683-478		背面カバー BACK COVER	1	11		1	
1K683-479 1K683-479		SD蓋 SD COVER	1	11	1F998-313	5	
1K683-480 1K683-480		SD蓋ブロック SD COVER BLOCK	1	11	1F998-313	5	
1K683-546 1K683-546		SBケース回転部カラー COLLAR	1	8		5	
1S020-444 1S020-444		SB基板 SB BASE PLATE	1	5		1	△ OLD RP07047
△ 1S020-444-1 1S020-444-1		SB基板 SB BASE PLATE	1	5		1	NEW RP07047
1S020-445 1S020-445		中継基板 RELAY PCB	1	4		1	
1S020-450 1S020-450		前面ボディFPC FRONT BODY FPC	1	3, 3-1	1C999-476 1C999-476-1	1	RP07022
1S020-451 1S020-451		SI LED-FPC SI LED-FPC	1	3-1	1C999-476-1	5	RP07022
1S020-453 1S020-453		背面FPC REAR FPC	1	11		5	

Parts List

D40(Black)

VBA15001-R.3701.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1S045-416		接続ハーネス	1	9		5	
1S045-416		HARNESS					
△ 1S144-003		IGBT	1	5	1S020-444-1	10	RP07054
1S144-003		IGBT					
1S422-090		マルチセレクターSW	1	11		5	
1S422-090		MULTI SELECTOR SW					
* 1S424-045		リリースSW	1	9	1F998-291	5	
1S424-045		RELEASE SW					
* 1S477-001		SDカードホルダー	1	10		5	
1S477-001		SD CARD HOLDER					
1S570-003		TFTモニター	1	11		1	
1S570-003		TFT MONITOR					
1S598-005		DC/DC基板	1	1		1	
1S598-005		DC/DC PCB UNIT					
1S598-008		メインコンデンサー	1	5		1	
1S598-008		MAIN CONDENSER					
1S705-934		SQ FPC	1	4		5	
1S705-934		SQ FPC					
1S705-936		接続FPC	1	9		5	
1S705-936		CONNECTION FPC					
1S705-937		接続FPC	1	4		5	
1S705-937		CONNECTION FPC					
1S705-938		接続FPC	1	5		5	
1S705-938		CONNECTION FPC					
1S758-137		ラバーSW	1	8		5	
1S758-137		RUBBER SW					
1S758-138		AF/AEロック釦ラバーSW	1	7	1C999-478	5	
1S758-138		AF/AE LOCK BUTTON RUBBER SW			1C999-475		
1S758-139		背面4連釦ラバーSW	1	11		5	
1S758-139		REAR PUSH BUTTON RUBBER SW					
1S758-140		背面削除釦ラバーSW	1	11		5	
1S758-140		REAR DELETE BUTTON RUBBER SW					
1S813-106		コード	1	1		5	
1S813-106		CORD					
1S813-107		コード	1	1		5	
1S813-107		CORD					

Parts List

D40(Black)

VBA15001-R.3701.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1S813-108		コード CORD	1	1		5	
1S813-109		コード CORD	1	1		5	
1S813-110		コード CORD	1	1		5	
1S813-111		コード CORD	1	1		5	
1S813-112		コード CORD	1	8		5	
1S813-113		コード CORD	1	4		5	
1S813-114		コード CORD	1	4		5	
1S813-115		コード CORD	1	4		5	
1S813-116		コード CORD	1	5		5	
1S813-117		コード CORD	1	5		5	
1S813-118		コード CORD	1	4		5	
1S813-119		コード CORD	1	4		5	
1S813-130		コード CORD	1	4		5	
1S813-131		コード CORD	1	4		5	
1S813-132		コード CORD	1	1		5	
△ 1S999-159		ヒューズ FUSE	1	1	1S598-005	10	RP07054
* 6K050-084		ワッシャー(T=0.02) WASHER(T=0.02)	0-n	10		10	
* 6K050-085		ワッシャー(T=0.1) WASHER(T=0.1)	0-n	10		10	

D40(Black)

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Parts List

D40(Silver)

VBA15101-R.3701.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1C999-475		上カバー部組(SILVER)	1	7		1	
1C999-475		TOP COVER UNIT(SILVER)					
△ 1F998-251		前カバー部組	1	9		1	RP07031
1F998-251		FRONT COVER UNIT					
△ 1F998-251N		前カバー部組	1	9		1	RP07031
1F998-251N		FRONT COVER UNIT					
1F998-278		リリース釦部組	1	8		1	
1F998-278		RELEASE BOTTON UNIT					
1F998-279		モードダイヤル部組	1	7		1	
1F998-279		MODE DIAL UNIT					
1F998-282		SD蓋部組	1	11		1	
1F998-282		SD COVER UNIT					
1K001-324		ネジ (L=5.5)	4	12		10	
1K001-324		SCREW (L=5.5)					
* 1K001-325		ネジ	2	9		10	
1K001-325		SCREW					
1K001-334		ネジ	4	12		10	
1K001-334		SCREW					
1K001-350		ネジ (L=5.0)	4	12		10	
1K001-350		SCREW (L=5.0)					
1K010-767		ネジ	4	9		10	
1K010-767		SCREW					
1K010-768		ネジ	2	12		10	
1K010-768		SCREW					
1K010-769		ネジ	5	12		10	
1K010-769		SCREW					
1K010-792		ネジ	2	11		10	
1K010-792		SCREW					
1K087-759		銘板	1	9	1F998-251	5	
1K087-759		NAME PLATE (SILVER)					
1K201-451		マルチセレクター	1	11		5	
1K201-451		MULTI SELECTOR					
1K201-452		OK釦	1	11		5	
1K201-452		OK BUTTON					
1K201-453		背面4連釦A	1	11		5	
1K201-453		REAR PUSH BUTTON A					

Parts List

<i>D40(Silver)</i>							VBA15101-R.3701.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
1K201-454 1K201-454		背面4連釦B REAR PUSH BUTTON B	1	11		5	
1K201-455 1K201-455		背面4連釦C REAR PUSH BUTTON C	1	11		5	
1K201-456 1K201-456		背面4連釦D REAR PUSH BUTTON D	1	11		5	
1K201-457 1K201-457		背面削除釦 REAR DELETE BUTTON	1	11		5	
1K201-461 1K201-461		＋－/絞り釦 ＋－/APERTURE BUTTON	1	8		5	
1K201-462 1K201-462		INFO.釦 INFO. BUTTON	1	8		5	
1K201-463 1K201-463		AF/AEロック釦 AF/AE LOCK BUTTON	1	7	1C999-475	5	
1K467-288 1K467-288		I/F蓋 I/F COVER	1	12		5	
1K467-289 1K467-289		電源コード蓋 POWER CABLE COVER	1	12		5	
1K467-290 1K467-290		SD蓋 SD COVER	1	11	1F998-282	5	
* 1K682-744-1 1K682-744		レンズ着脱釦カバー(シルバー) RELEASE BUTTON COVER(SILVER)	1	9		5	
1K683-483 1K683-483		底カバー BOTTOM COVER	1	12		1	
1K683-484 1K683-484		SB上ケース SB UPPER COVER	1	8		1	
1K683-485 1K683-485		背面カバー BACK COVER	1	11		1	
1K683-486 1K683-486		SD蓋ブロック SD COVER BLOCK	1	11	1F998-282	5	