

作成承認印

配布許可印



COOLPIX S5

VAA55022 (Silver)

VAA55102 (Red)

VAA55202 (White)

VAA55322 (Blue)

PARTS LIST

修理部品表

Nikon | **NIKON CORPORATION**
Tokyo, Japan

Copyright © 2006 by Nikon Corporation.
All Rights Reserved.
無断転載を禁ず !!





Fig. 1






Fig. 3

Parts List

Coolpix S5

VAA55022-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
404-105-5104 404-105-5104		メインコンデンサー MAIN CONDENSER UNIT	1	2	636-093-2005	5	
411-017-7300 411-017-7300		SCREW SCREW	1	1		10	
* 411-186-0409 411-186-0409		SCREW SCREW	8	1,2,3		10	
411-190-2901 411-190-2901		SCREW SCREW	2	2		10	
* 411-199-0700 411-199-0700		SCREW SCREW	2	1		10	
411-205-6900 411-205-6900		SCREW SCREW	5	1,2		10	
411-205-7006 411-205-7006		SCREW SCREW	4	2		10	
411-205-9802 411-205-9802		SCREW SCREW	9	1		10	
* 412-063-6101 412-063-6101		SCREW SCREW	1	3		10	
* 412-063-8600 412-063-8600		SCREW SCREW	5	1		10	
423-031-5606 423-031-5606		ヒューズ [*] 32V 2A FUSE 32V 2A	5	2	636-093-2005	10	
636-094-1427 606-094-1427		製造番号シール (INDONESIA) LABEL SERIAL(INDONESIA)	0-1	1		5	
* 636-069-2725 636-069-2725		原産地シール LABEL SEAL	0-1	1		5	
* 636-069-2732 636-069-2732		原産国シール INDONESIA COUNTRY ORIGIN SEAL III	0-1	1		5	
* 636-084-1406 636-084-1406		スプリング [*] SPRING	1	2		5	
* 636-086-6614 636-086-6614		スペーサー (レンズ) SPACER (LENS)	1	2		5	
* 636-086-6621 636-086-6621		シャフト SHAFT	1	3		5	

Parts List

Coolpix S5							VAA55022-R.3684.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 636-086-6898 636-086-6898		スペーサー (LED) SPACER (LED)	1	2		5	
* 636-088-1310 636-088-1310		スペーサー SPACER	1	2		5	
* 636-091-6227 636-091-6227		スペーサー SPACER	1	2	636-093-2005	5	
636-092-3065 636-092-3065		バリヤー(シルバー) BARRIER (SILVER)	1	3		5	
636-092-3454 636-092-3454		上カバー(シルバー) TOP COVER (SILVER)	1	2		5	
636-092-3461 636-092-3461		ズームボタン ZOOM BUTTON	1	2		5	
636-092-3485 636-092-3485		リリースボタン RELEASE BUTTON	1	2		5	
636-092-3492 636-092-3492		電源SWボタン POWER SW BUTTON	1	2		5	
636-092-3508 636-092-3508		顔認識釦(シルバー) FACE PRIORITY BUTTON (SILVER)	1	2		5	
636-092-3515 636-092-3515		LED LED	1	2		5	
636-092-3539 636-092-3539		窓 WINDOW	1	1		5	
636-092-3546 636-092-3546		バッテリーホルダーC (シルバー) BATTERY HOLDER C (SILVER)	1	3		5	
636-092-3553 636-092-3553		ロックレバー LOCK LEVER	1	3		5	
636-092-3560 636-092-3560		バッテリーカバー (シルバー) BATTERY COVER (SILVER)	1	3		5	
636-092-3577 636-092-3577		トップパネル PANEL	1	2		5	
636-092-3584 636-092-3584		三脚座(シルバー) TRIPOD SOCKET (SILVER)	1	2		5	
636-092-3614 636-092-3614		右インナープレート INNER PLATE (RIGHT)	1	1		5	

Parts List

Coolpix S5

VAA55022-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
636-092-3621 636-092-3621		左インナープレート INNER PLATE (LEFT)	1	1		5	
636-092-3645 636-092-3645		ストラップホルダー STRAP HOLDER	1	1		5	
636-092-6011 636-092-6011		TB-1 ユニット TB-1 UNIT	1	2		5	
636-092-6028 636-092-6028		TB-2 ユニット TB-2 UNIT	1	2		5	
636-092-6035 636-092-6035		TB-3 ユニット TB-3 UNIT	1	2		5	
636-092-6080 636-092-6080		パッド PAD	1	2		5	
636-092-6097 636-092-6097		スピーカーホルダー SPEAKER HOLDER	1	2		5	
636-092-6110 636-092-6110		ホルダー HOLDER	1	1		5	
636-092-6158 636-092-6158		バッテリーホルダーB BATTERY HOLDER B	1	3		5	
636-092-6189 636-092-6189		モニターホルダー MONITOR HOLDER	1	1		5	
636-092-6196 636-092-6196		モニターガラス MONITOR GLASS	1	1		5	
636-092-7452 636-092-7452		シャフト SHAFT	1	2		5	
636-092-7469 636-092-7469		両面テープ ADHESIVE DOUBLE COATED TAPE	1	2		5	
636-092-7476 636-092-7476		両面テープ ADHESIVE DOUBLE COATED TAPE	1	2		5	
636-092-7483 636-092-7483		スペーサー SPACER	1	2		5	
636-092-7490 636-092-7490		アース EARTH	1	2		5	
636-092-7506 636-092-7506		アース EARTH	1	2		5	

Parts List

Coolpix S5

VAA55022-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
636-092-7520 636-092-7520		アース EARTH	1	2		5	
636-092-7537 636-092-7537		スペーサー SPACER	1	2		5	
636-092-7544 636-092-7544		両面テープ ADHESIVE DOUBLE COATED TAPE	1	2		5	
636-092-7575 636-092-7575		電池接点 BATTERY CONTACT	1	3		5	
636-092-7582 636-092-7582		バッテリーラベル BATTERY LABEL	1	3		5	
636-092-7599 636-092-7599		スプリング SPRING	1	3		5	
636-092-7636 636-092-7636		アース EARTH	4	1		5	
636-092-7643 636-092-7643		アース EARTH	1	3		5	
636-092-8190 636-092-8190		スペーサー SPACER	1	2	636-093-2005	5	
636-092-8893 636-092-8893		スペーサー SPACER	1	3		5	
636-092-9876 636-092-9876		前カバー(シルバー) FRONT COVER (SILVER)	1	2		1	
636-092-9890 636-092-9890		後カバー(シルバー) REAR COVER (SILVER)	1	1		1	
636-092-9913 636-092-9913		右カバー COVER (RIGHT)	1	1		5	
636-092-9920 636-092-9920		左カバー COVER (LEFT)	1	1		5	
636-092-9951 636-092-9951		両面テープ ADHESIVE DOUBLE COATED TAPE	1	1		5	
636-092-9968 636-092-9968		両面テープ ADHESIVE DOUBLE COATED TAPE	1	1		5	
636-092-9975 636-092-9975		両面テープ ADHESIVE DOUBLE COATED TAPE	2	1		5	

Parts List

Coolpix S5

VAA55022-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
636-092-9982		両面テープ	1	1		5	
636-092-9982		ADHESIVE DOUBLE COATED TAPE					
636-093-0643		定格銘板	1	1		5	
636-093-0643		LICENSE SHEET					
636-093-0650		製造番号シール(J)2-	0-1	1		5	
636-093-0650		LABEL SERIAL(J)2-					
636-093-0650-EU		製造番号シール(EU)4-	0-1	1		5	
636-093-0650-EU		LABEL SERIAL(EU)4-					
636-093-0650-U		製造番号シール(U)3-	0-1	1		5	
636-093-0650-U		LABEL SERIAL(U)3-					
636-093-0704		ラベルポップ	1	1		5	
636-093-0704		LABEL POP					
636-093-2005		メインPCBユニット CP-1	1	2		1	
636-093-2005		MAIN PCB UNIT CP-1					
636-093-3422		FPC	1	2		5	
636-093-3422		FPC					
636-093-3446		SW FPC	1	1		5	
636-093-3446		SW FPC					
636-093-5464		スペーサー	1	3		5	
636-093-5464		SPACER					
636-093-6973		スペーサー	2	1		5	
636-093-6973		SPACER					
636-093-7574		両面テープ	1	3		5	
636-093-7574		ADHESIVE DOUBLE COATED TAPE					
636-093-7642		スペーサー	1	1		5	
636-093-7642		SPACER					
636-093-8557		スペーサー	1	1		5	
636-093-8557		SPACER					
636-093-9356		シールドテープ	1	1		5	
636-093-9356		SHIELD TAPE					
636-094-1434		製造番号シール (NIKON)	0-1	1		5	
636-094-1434		LABEL SERIAL(NIKON)					
636-094-4992		スペーサー	1	1		5	
636-094-4992		SPACER					

Parts List

Coolpix S5

VAA55022-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
636-094-5005 636-094-5005		スペーサー SPACER	2	1		5	
636-094-5012 636-094-5012		スペーサー SPACER	1	2		5	
636-094-5128 636-094-5128		製造番号シール (KOREA) LABEL SERIAL(KOREA)	0-1	1		5	
636-094-5500 636-094-5500		CA-1 ユニット CA-1 UNIT	1	2		1	
636-094-9980 636-094-9980		スペーサー SPACER	1	2		5	
636-095-0658 636-095-0658		ボタン BUTTON	1	1		5	
636-095-0665 636-095-0665		コントロールユニットホルダー CONTROL UNIT HOLDER	1	1		5	
636-095-0931 636-095-0931		スペーサー SPACER	1	2		5	
636-095-0955 636-095-0955		両面テープ ADHESIVE DOUBLE COATED TAPE	1	2		5	
636-095-0962 636-095-0962		スペーサー SPACER	1	2		5	
636-095-1730 636-095-1730		両面テープ ADHESIVE DOUBLE COATED TAPE	1	2		5	
636-095-1846 636-095-1846		スペーサー SPACER	1	2		5	
636-095-1853 636-095-1853		スペーサー SPACER	1	2	636-093-2005	5	
636-095-1860 636-095-1860		スペーサー SPACER	1	2		5	
636-095-2928 636-095-2928		スペーサー SPACER	1	3		5	
636-095-4083 636-095-4083		スペーサー SPACER	1	3		5	
636-095-4113 636-095-4113		スペーサー SPACER	1	1		5	

Parts List

Coolpix S5



VAA55022-R.3684.A

Part Number Part Code	Barcode (Part Code)	部 品 名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
636-095-5820 636-095-5820		レンズ シェード LENS SHADE	1	2		5	
636-095-5967 636-095-5967		スペーサー SPACER	1	2		5	
636-095-6285 636-095-6285		バッテリーホルダー-A BATTERY HOLDER A	1	3		5	
636-095-7046 636-095-7046		LCD ユニット LCD UNIT	1	1		1	
* 645-073-6063 645-073-6063		バリヤーモーターユニット BARRIER MOTOR UNIT	1	3		5	
645-076-3960 645-076-3960		マルチコネクターソケット MULTI CONNECTOR SOCKET	1	2	636-093-2005	5	
645-078-8499 645-078-8499		マイクロフォン MICROPHONE	1	2		5	
645-081-7830 645-081-7830		SDカードソケット SD CARD SOCKET	1	2	636-093-2005	5	
645-082-0496 645-082-0496		コントロールユニット CONTROL UNIT	1	1		5	
645-082-1127 645-082-1127		発光管 FLASH TUBE	1	2	636-093-2005	5	
645-083-5049 645-083-5049		スピーカー SPEAKER	1	2		5	
* 527 VAA35001-527		シート 1 SEAT 1	1	2	636-094-5500	5	
* 528 VAA35001-528		シート 2 SEAT 2	1	2	636-094-5500	5	
* 536 VAA35001-536		シャッターユニット SHUTTER UNIT	1	2	636-094-5500	5	

Parts List

Coolpix S5 RED



VAA55102-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 411-195-2005		SCREW	3	1, 3		10	
411-195-2005		SCREW					
* 411-205-7105		SCREW	1	1		10	
411-205-7105		SCREW					
636-093-9615		前カバー(赤)	1	3		1	
636-093-9615		FRONT COVER (RED)					
636-093-9639		後カバー(赤)	1	1		1	
636-093-9639		REAR COVER (RED)					
636-093-9660		バリヤー(赤)	1	3		5	
636-093-9660		BARRIER (RED)					
636-093-9684		顔認識釦(赤)	1	2		5	
636-093-9684		FACE PRIORITY BUTTON (RED)					
636-093-9691		上カバー(赤)	1	2		5	
636-093-9691		TOP COVER (RED)					
636-093-9707		バッテリーカバー (赤)	1	3		5	
636-093-9707		BATTERY COVER (RED)					
636-093-9714		バッテリーホルダーC (赤)	1	3		5	
636-093-9714		BATTERY HOLDER C (RED)					
636-093-9721		三脚座(赤)	1	3		5	
636-093-9721		TRIPOD SOCKET (RED)					

Parts List

WHITE



VAA55202-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs/ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 412-063-6101		SCREW	3	1, 3		10	
412-063-6101		SCREW					
* 412-063-8600		SCREW	1	1		10	
412-063-8600		SCREW					
636-093-9752		前カバー(白)	1	3		1	
636-093-9752		FRONT COVER (WHITE)					
636-093-9776		後カバー(白)	1	1		1	
636-093-9776		REAR COVER (WHITE)					
636-093-9868		バリヤー(白)	1	3		5	
636-093-9868		BARRIER (WHITE)					
636-093-9905		顔認識釦(白)	1	2		5	
636-093-9905		FACE PRIORITY BUTTON (WHITE)					
636-093-9936		上カバー(白)	1	2		5	
636-093-9936		TOP COVER (WHITE)					
636-093-9967		バッテリーカバー(白)	1	3		5	
636-093-9967		BATTERY COVER (WHITE)					
636-093-9981		バッテリーホルダーC(白)	1	3		5	
636-093-9981		BATTERY HOLDER C (WHITE)					
636-094-0000		三脚座(白)	1	3		5	
636-094-0000		TRIPOD SOCKET (WHITE)					

Parts List

Coolpix S5 BLUE

VAA55322-R.3684.A

Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 411-195-2005		SCREW	3	1, 3		10	
411-195-2005		SCREW					
* 411-205-7105		SCREW	1	1		10	
411-205-7105		SCREW					
636-093-9813		前カバー(青)	1	3		1	
636-093-9813		FRONT COVER (BLUE)					
636-093-9837		後カバー(青)	1	1		1	
636-093-9837		REAR COVER (BLUE)					
636-093-9875		バリアー(青)	1	3		5	
636-093-9875		BARRIER (BLUE)					
636-093-9912		顔認識釦(青)	1	2		5	
636-093-9912		FACE PRIORITY BUTTON (BLUE)					
636-093-9950		上カバー(青)	1	2		5	
636-093-9950		TOP COVER (BLUE)					
636-093-9974		バッテリーカバー(青)	1	3		5	
636-093-9974		BATTERY COVER (BLUE)					
636-093-9998		バッテリーホルダーC(青)	1	3		5	
636-093-9998		BATTERY HOLDER C (BLUE)					
636-094-0017		三脚座(青)	1	3		5	
636-094-0017		TRIPOD SOCKET (BLUE)					